


Bowl-Tronics Enterprises Incorporated

Address: 1115 Sherwood Ave.
Elgin IL. 60120
Website: www.bowl-tronics.com
E-mail: rick@bowl-tronics.com

Phone: 847-741-4500
Fax: 847-741-0914

Commander Series 1Ball Lift Motor Control Box AMF (BTC-S1/AMF)



PC Board Layout Description Table:

1. High Voltage Input
2. High Voltage Output (Motor's)
3. Output Active LED (When Motor is running LED will be lit)
4. Input Active LED (AMF 82-70 when motor is running LED will be lit)
5. Input Active LED (Brunswick odd lane when motor is running LED will be lit)
6. Input Active LED (Brunswick even lane when motor is running LED will be lit)
7. Continuity Input (AMF 82-70 M-2 relay hook up)
8. 24 VAC Output (Brunswick ball lift control voltage odd lane)
9. 24 VAC Input (From Brunswick accelerator chassis odd lane)
10. 24 VAC Input (From Brunswick accelerator chassis even lane)
11. 24 VAC Output (Brunswick ball lift control voltage even lane)

Ball Lift Motor Control Box Theory

This ball lift motor control box is designed to replace the existing AMF ball lift box or similar ball lift box. On the inside cover of the (BTC-S1/AMF) there will be a schematic on how to wire the (BTC-S1/AMF). It will also be included in this manual. Point closure from the AMF machine turns on the solid-state control circuit, this closes the circuit to start your ball lift and hand dryer motor running.

Installation Instructions

Remember to remove power before performing any installation!!

First, start by removing the old ball lift box. Next, you will utilize the main power cable, ball lift motor cable, hand dryer cable, and the M2 relay wire from the machines. Start by installing your main power connection to the new (BTC-S1/AMF) box. Next, install the ball lift motor cable to the (BTC-S1/AMF) box. The hand dryer output will have a 5 ft black SJOW cable or a 3/8" cable clamp. The SJOW cable will splice into your hand dryer motor and with the 3/8" cable clamp you supply the cable. View the schematic to help wire up all the connections to the (BTC-S1/AMF) box. Finally, hook up the M2 relay wires coming from the machines to the (BTC-S1/AMF) box via the quick disconnect connectors.

For Repair Send Faulty Parts to:

**Address: BOWL-TRONICS
1115 Sherwood Ave
Elgin IL. 60120**


**Phone: 847-741-4500
Fax: 847-741-0914**

Visit our web site at www.bowl-tronics.com

Notes:

Ball Lift Motor Control Box AMF Schematic

BALL LIFT MOTOR CONTROL CHASSIS 120 VAC INPUT



BALL LIFT MOTOR CONTROL CHASSIS 220 VAC INPUT

