

Bowl-Tronics Enterprises Incorporated

Address: 1115 Sherwood Ace.
Elgin IL. 60120
Website: www.bowl-tronics.com
E-mail: rick@bowl-tronics.com

Phone: 847-741-4500
Fax: 847-741-0914

Block Out Switch (BOS)


Block Out Switch Theory (*Brunswick Machine Only*)

The switch assembly is used when you want to mount the infrared triggering optics behind the rake board of your machine. The way it works is when the switch is fully depressed the triggering is able to activate. When the switch lever is up the triggering system will be shutdown.

Installation Instructions

Remember to remove power before performing any installation!!

First, you must locate the 4 to 1 shaft of your Brunswick gearbox. Next, you will loosen the top 4 to 1 bolt and remove the nut. Slide the bracket and onto the bolt and tighten nut. Be sure the switch lever is completely under the actuator lever and the switch is fully closed. Finally, you will plug in the switch to the main PCM triggering board. Hook the wires together and match the colors. One wire will be marked left on the PCM board, so connect the BOS marked left to it. (*See picture below*)



For Repair Send Faulty Parts to:

Address: BOWL-TRONICS
1115 Sherwood Ave
Elgin IL. 60120

Phone: 847-741-4500
Fax: 847-741-0914

Visit our web site at www.bowl-tronics.com